


PRODUCT LINE: ACCESS

PRODUCT NAME: HF500-Cotag reader

MODEL(S): V24246-F4106-A1 **CATEGORY:** END OF LIFE

CONTACT: Local Customer Support **DATE:** 30-11-2017

The HF500-Cotag reader is being discontinued. The HF100-Cotag reader and the 5311 reader interface will be offered as a direct replacement options. Details of the two solutions are outlined below:



Overview of differences between the two solutions:

	HF500-Cotag	HF100-Cotag
Reading range	<ul style="list-style-type: none"> 109cm active Cotag cards 34cm passive Cotag cards 	<ul style="list-style-type: none"> 112cm active Cotag cards 35cm passive Cotag cards
Installation scenario	<ul style="list-style-type: none"> Mounted indoors, however can read cards presented from outside if environment permits. 	<ul style="list-style-type: none"> Mounted outdoors, but requires 5311 reader interface, which is mounted indoors. The 5311 will have to be installed separately as it does not fit in controller housing.
Outdoor standard	No	Yes
System overview	<ul style="list-style-type: none"> Granta: <ul style="list-style-type: none"> 4101-3 -> 4422 -> HF500 Entro: <ul style="list-style-type: none"> DC22 -> HF500 SiPass: <ul style="list-style-type: none"> 4101-3 (migrated) -> 4422 -> HF500 SSRI/DRI -> HF500 	<ul style="list-style-type: none"> Granta: <ul style="list-style-type: none"> 4101-3 -> 4322 -> HF100 4101-3 -> 4422 -> 5311-> HF100 Entro: <ul style="list-style-type: none"> DC22 -> 5311 -> HF100 SiPass: <ul style="list-style-type: none"> 4101-3 (migrated) -> 4322 -> HF100 4101-3 (migrated) -> 4422 -> 5311 -> HF100 SRI/DRI -> 5311 -> HF100